

How to read this list:	
Mark	Description
√	Function is supported.
*	Function is added or developed newly

V30/PC-MAX Function List													
Automaker:				HONDA									
Software Version:				V4.3									
Brand	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
HONDA	All	1996-2009	All	All	All	PGM FI		√	√	√	√		
HONDA	All	1996-2009	All	All	All	AT		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	SRS		√	√	√	√		OPDS init
HONDA	All	1996-2009	All	All	All	EPS		√	√	√	√		
HONDA	All	1996-2009	All	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Power Sliding Door)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Power Tailgate)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Auto Light Leveling)		√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	BODY(Power Seat/Power Mirror)		√	√	√	√	√	

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

HONDA	All	1996-2009	All	All	All	BODY(Adaptive Front Lighting)	√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	IMMOBI						Key program
HONDA	All	1996-2009	All	All	All	IMA	√	√	√	√	√	
HONDA	All	1996-2009	All	All	All	TPMS	√	√	√	√		
HONDA	All	2010	ACOORD	2.4L		PGM FI	*	*	*	*		TP sensor reset
HONDA	All	2010	ACOORD	2.4L		AT	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		ABS TCS VSA	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		SRS	*	*	*	*		OPDS init
HONDA	All	2010	ACOORD	2.4L		SMART KEY	*	*	*	*		
HONDA	All	2010	ACOORD	2.4L		BODY(Gauges)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(Lighting)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(Door Locks)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(Keyless)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(Power Windows)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(Wiper)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(Security)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(HVAC/Climate control)	*	*	*	*	*	
HONDA	All	2010	ACOORD	2.4L		BODY(Auto Light Leveling)	*	*	*	*	*	
HONDA	All	2008-2009	ACOORD	All	All	PGM FI	√	√	√	√		TP sensor reset
HONDA	All	2008-2009	ACOORD	All	All	AT	√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	SRS	√	√	√	√		
HONDA	All	2008-2009	ACOORD	All	All	EPS	√	√	√	√		
HONDA	All	2008-2009	ACOORD	All	All	BODY(Gauges)	√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	BODY(Lighting)	√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	BODY(Door Locks)	√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	BODY(Keyless)	√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	BODY(Power Windows)	√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	BODY(Wiper)	√	√	√	√	√	

HONDA	All	2008-2009	ACOORD	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2008-2009	ACOORD	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	PGM FI		√	√	√	√		
HONDA	All	2002-2007	ACOORD	All	All	AT		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	SRS		√	√	√	√		OPDS init
HONDA	All	2002-2007	ACOORD	All	All	EPS		√	√	√	√		
HONDA	All	2002-2007	ACOORD	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2002-2007	ACOORD	All	All	IMMOBI							Key program
HONDA	All	1996-2001	ACOORD	All	All	PGM FI		√	√	√	√		
HONDA	All	1996-2001	ACOORD	All	All	AT		√	√	√	√	√	
HONDA	All	1996-2001	ACOORD	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	1996-2001	ACOORD	All	All	SRS		√	√	√	√		
HONDA	All	1996-2001	ACOORD	All	All	EPS		√	√	√	√		
HONDA	All	2000-2009	ACTY VAN	All	All	PGM FI		√	√	√	√		
HONDA	All	2000-2009	ACTY VAN	All	All	AT		√	√	√	√	√	
HONDA	All	2000-2009	ACTY VAN	All	All	SRS		√	√	√	√		
HONDA	All	2000-2009	ACTY VAN	All	All	EPS		√	√	√	√		
HONDA	All	2005	AIRWAVE	All	All	PGM FI		√	√	√	√		
HONDA	All	2005	AIRWAVE	All	All	AT		√	√	√	√	√	
HONDA	All	2005	AIRWAVE	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2005	AIRWAVE	All	All	SRS		√	√	√	√		

HONDA	All	2005	AIRWAVE	All	All	EPS		√	√	√	√		
HONDA	All	2003-2006	AIRA	All	All	PGM FI		√	√	√	√		
HONDA	All	2003-2006	AIRA	All	All	AT		√	√	√	√	√	
HONDA	All	2003-2006	AIRA	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2003-2006	AIRA	All	All	SRS		√	√	√	√		
HONDA	All	2003-2006	AIRA	All	All	EPS		√	√	√	√		
HONDA	All	2003-2006	AVANCIER	GH-TA1	All	PGM FI		√	√	√	√		
HONDA	All	2003-2006	AVANCIER	GH-TA1	All	AT		√	√	√	√	√	
HONDA	All	2003-2006	AVANCIER	GH-TA1	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2003-2006	AVANCIER	GH-TA1	All	SRS		√	√	√	√		
HONDA	All	2009	CITY	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2009	CITY	All	All	AT		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	SRS		√	√	√	√		
HONDA	All	2009	CITY	All	All	EPS		√	√	√	√		
HONDA	All	2009	CITY	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2009	CITY	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2005-2009	CIVIC	All	All	AT		√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	SRS		√	√	√	√		
HONDA	All	2005-2009	CIVIC	All	All	EPS		√	√	√	√		
HONDA	All	2005-2009	CIVIC	All	All	BODY(Gauges)		√	√	√	√	√	

HONDA	All	2005-2009	CIVIC	All	All	BODY(Lighting)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	BODY(Door Locks)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	BODY(Keyless)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	BODY(Power Windows)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	BODY(Wiper)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	BODY(Security)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC	All	All	BODY(HVAC/Climate control)	√	√	√	√	√	
HONDA	All	2000-2005	CIVIC	All	All	PGM FI	√	√	√	√		
HONDA	All	2000-2005	CIVIC	All	All	AT	√	√	√	√	√	
HONDA	All	2000-2005	CIVIC	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2000-2005	CIVIC	All	All	SRS	√	√	√	√		
HONDA	All	2000-2005	CIVIC	All	All	EPS	√	√	√	√		
HONDA	All	2005-2009	CIVIC HYBRID	All	All	PGM FI	√	√	√	√		TP sensor reset
HONDA	All	2005-2009	CIVIC HYBRID	All	All	AT	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	SRS	√	√	√	√		
HONDA	All	2005-2009	CIVIC HYBRID	All	All	EPS	√	√	√	√		
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(Gauges)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(Lighting)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(Door Locks)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(Keyless)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(Power Windows)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(Wiper)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(Security)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	BODY(HVAC/Climate control)	√	√	√	√	√	
HONDA	All	2005-2009	CIVIC HYBRID	All	All	IMA						
HONDA	All	2000-2005	CIVIC HYBRID	All	All	PGM FI	√	√	√	√		
HONDA	All	2000-2005	CIVIC HYBRID	All	All	AT	√	√	√	√	√	
HONDA	All	2000-2005	CIVIC HYBRID	All	All	ABS TCS VSA	√	√	√	√	√	

HONDA	All	2000-2005	CIVIC HYBRID	All	All	SRS		√	√	√	√		
HONDA	All	2000-2005	CIVIC HYBRID	All	All	EPS		√	√	√	√		
HONDA	All	2000-2005	CIVIC HYBRID	All	All	IMA		√	√	√	√	√	
HONDA	All	2005-2009	CIVIC TYPE-R	All	All	PGM FI		√	√	√	√		
HONDA	All	2005-2009	CIVIC TYPE-R	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2005-2009	CIVIC TYPE-R	All	All	SRS		√	√	√	√		
HONDA	All	2005-2009	CIVIC TYPE-R	All	All	EPS		√	√	√	√		
HONDA	All	2008-2009	CR-V	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2008-2009	CR-V	All	All	AT		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	SRS		√	√	√	√		
HONDA	All	2008-2009	CR-V	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2008-2009	CR-V	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2002-2007	CR-V	All	All	PGM FI		√	√	√	√		
HONDA	All	2002-2007	CR-V	All	All	AT		√	√	√	√	√	
HONDA	All	2002-2007	CR-V	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2002-2007	CR-V	All	All	SRS		√	√	√	√		
HONDA	All	2002-2007	CR-V	All	All	EPS		√	√	√	√		
HONDA	All	1998-2001	CR-V	All	All	PGM FI		√	√	√	√		
HONDA	All	1998-2001	CR-V	All	All	AT		√	√	√	√	√	
HONDA	All	1998-2001	CR-V	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	1998-2001	CR-V	All	All	SRS		√	√	√	√		
HONDA	All	2006-2009	CROSSROAD	All	All	PGM FI		√	√	√	√		TP sensor reset

HONDA	All	2006-2009	CROSSROAD	All	All	AT		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	SRS		√	√	√	√		
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2006-2009	CROSSROAD	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2004	EDIX	All	All	PGM FI		√	√	√	√		
HONDA	All	2004	EDIX	All	All	AT		√	√	√	√	√	
HONDA	All	2004	EDIX	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2004	EDIX	All	All	SRS		√	√	√	√		
HONDA	All	2004	ELEMENT	All	All	PGM FI		√	√	√	√		
HONDA	All	2004	ELEMENT	All	All	AT		√	√	√	√	√	
HONDA	All	2004	ELEMENT	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2004	ELEMENT	All	All	SRS		√	√	√	√		
HONDA	All	2004	ELYSION	All	All	PGM FI		√	√	√	√		
HONDA	All	2004	ELYSION	All	All	AT		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	SRS		√	√	√	√		
HONDA	All	2004	ELYSION	All	All	EPS		√	√	√	√		
HONDA	All	2004	ELYSION	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	BODY(Power Windows)		√	√	√	√	√	

HONDA	All	2004	ELYSION	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2004	ELYSION	All	All	BODY(Power Sliding Door)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2008-2009	FIT	All	All	AT		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	SRS		√	√	√	√		
HONDA	All	2008-2009	FIT	All	All	EPS		√	√	√	√		
HONDA	All	2008-2009	FIT	All	All	TPMS		√	√	√	√		
HONDA	All	2008-2009	FIT	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2008-2009	FIT	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2001-2007	FIT	All	All	PGM FI		√	√	√	√		
HONDA	All	2001-2007	FIT	All	All	AT		√	√	√	√	√	
HONDA	All	2001-2007	FIT	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2001-2007	FIT	All	All	SRS		√	√	√	√		
HONDA	All	2001-2007	FIT	All	All	EPS		√	√	√	√		
HONDA	All	2001-2007	FIT	All	All	IMMOBI							Key program
HONDA	All	2008-2009	FREED	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2008-2009	FREED	All	All	AT		√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	SRS		√	√	√	√		
HONDA	All	2008-2009	FREED	All	All	EPS		√	√	√	√		

HONDA	All	2008-2009	FREED	All	All	BODY(Gauges)	√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	BODY(Lighting)	√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	BODY(Door Locks)	√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	BODY(Keyless)	√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	BODY(Power Windows)	√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	BODY(Wiper)	√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	BODY(Security)	√	√	√	√	√	
HONDA	All	2008-2009	FREED	All	All	BODY(HVAC/Climate control)	√	√	√	√	√	
HONDA	All	1999-2001	HR-V	All	All	PGM FI	√	√	√	√		
HONDA	All	1999-2001	HR-V	All	All	AT	√	√	√	√	√	
HONDA	All	1999-2001	HR-V	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	1999-2001	HR-V	All	All	SRS	√	√	√	√		
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	PGM FI	√	√	√	√		TP sensor reset
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	AT	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	SRS	√	√	√	√		
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	EPS	√	√	√	√		
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	BODY(Gauges)	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	BODY(Lighting)	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	BODY(Door Locks)	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	BODY(Keyless)	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	BODY(Wiper)	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	BODY(Security)	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	BODY(HVAC/Climate control)	√	√	√	√	√	
HONDA	All	2007-2009	INSIGHT HYBRID	All	All	IMA						
HONDA	All	2000-2007	INSIGHT HYBRID	All	All	PGM FI	√	√	√	√		
HONDA	All	2000-2007	INSIGHT HYBRID	All	All	AT	√	√	√	√	√	
HONDA	All	2000-2007	INSIGHT HYBRID	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2000-2007	INSIGHT HYBRID	All	All	SRS	√	√	√	√		

HONDA	All	2000-2007	INSIGHT HYBRID	All	All	EPS		√	√	√	√		
HONDA	All	2000-2007	INSIGHT HYBRID	All	All	IMA		√	√	√	√		
HONDA	All	2002-2007	INSPIRE	All	All	PGM FI		√	√	√	√		
HONDA	All	2002-2007	INSPIRE	All	All	AT		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	SRS		√	√	√	√		
HONDA	All	2002-2007	INSPIRE	All	All	EPS		√	√	√	√		
HONDA	All	2002-2007	INSPIRE	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2002-2007	INSPIRE	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2001-2005	JAZZ	All	All	PGM FI		√	√	√	√		
HONDA	All	2001-2005	JAZZ	All	All	AT		√	√	√	√	√	
HONDA	All	2001-2005	JAZZ	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2001-2005	JAZZ	All	All	SRS		√	√	√	√		
HONDA	All	2001-2005	JAZZ	All	All	EPS		√	√	√	√		
HONDA	All	2000-2002	LAGREAT	All	All	PGM FI		√	√	√	√		
HONDA	All	2000-2002	LAGREAT	All	All	AT		√	√	√	√	√	
HONDA	All	2000-2002	LAGREAT	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2000-2002	LAGREAT	All	All	SRS		√	√	√	√		
HONDA	All	2007	LEGEND	All	All	PGM FI		√	√	√	√		
HONDA	All	2007	LEGEND	All	All	AT		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	SRS		√	√	√	√		
HONDA	All	2007	LEGEND	All	All	EPS		√	√	√	√		

HONDA	All	2007	LEGEND	All	All	SH-AWD							
HONDA	All	2007	LEGEND	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2007	LEGEND	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2008-2009	LIFE	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2008-2009	LIFE	All	All	AT		√	√	√	√	√	
HONDA	All	2008-2009	LIFE	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2008-2009	LIFE	All	All	SRS		√	√	√	√		
HONDA	All	2008-2009	LIFE	All	All	EPS		√	√	√	√		
HONDA	All	2000-2007	LIFE	All	All	PGM FI		√	√	√	√		
HONDA	All	2000-2007	LIFE	All	All	AT		√	√	√	√	√	
HONDA	All	2000-2007	LIFE	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2000-2007	LIFE	All	All	SRS		√	√	√	√		
HONDA	All	2000-2007	LIFE	All	All	EPS		√	√	√	√		
HONDA	All	2002-2005	MOBILIO	All	All	PGM FI		√	√	√	√		
HONDA	All	2002-2005	MOBILIO	All	All	AT		√	√	√	√	√	
HONDA	All	2002-2005	MOBILIO	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2002-2005	MOBILIO	All	All	SRS		√	√	√	√		
HONDA	All	2002-2005	MOBILIO	All	All	EPS		√	√	√	√		
HONDA	All	2010	ODYSSEY	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2010	ODYSSEY	All	All	AT		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	SRS		√	√	√	√		
HONDA	All	2010	ODYSSEY	All	All	BODY(Gauges)		√	√	√	√	√	

HONDA	All	2010	ODYSSEY	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2010	ODYSSEY	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2008-2009	ODYSSEY	All	All	AT		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	SRS		√	√	√	√		
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2008-2009	ODYSSEY	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	PGM FI		√	√	√	√		
HONDA	All	2001-2007	ODYSSEY	All	All	AT		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	SRS		√	√	√	√		
HONDA	All	2001-2007	ODYSSEY	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	BODY(Wiper)		√	√	√	√	√	

HONDA	All	2001-2007	ODYSSEY	All	All	BODY(Security)	√	√	√	√	√	
HONDA	All	2001-2007	ODYSSEY	All	All	BODY(HVAC/Climate control)	√	√	√	√	√	
HONDA	All	1998-2000	ODYSSEY	All	All	PGM FI	√	√	√	√		
HONDA	All	1998-2000	ODYSSEY	All	All	AT	√	√	√	√	√	
HONDA	All	1998-2000	ODYSSEY	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	1998-2000	ODYSSEY	All	All	SRS	√	√	√	√		
HONDA	All	2002	PRELUDE	All	All	PGM FI	√	√	√	√		
HONDA	All	2002	PRELUDE	All	All	AT	√	√	√	√	√	
HONDA	All	2002	PRELUDE	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2002	PRELUDE	All	All	SRS	√	√	√	√		
HONDA	All	2002	S2000	All	All	PGM FI	√	√	√	√		
HONDA	All	2002	S2000	All	All	AT	√	√	√	√	√	
HONDA	All	2002	S2000	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2002	S2000	All	All	SRS	√	√	√	√		
HONDA	All	2002	S2000	All	All	EPS	√	√	√	√		
HONDA	All	2002-2005	SPIKE	All	All	PGM FI	√	√	√	√		
HONDA	All	2002-2005	SPIKE	All	All	AT	√	√	√	√	√	
HONDA	All	2002-2005	SPIKE	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2002-2005	SPIKE	All	All	SRS	√	√	√	√		
HONDA	All	2002-2005	SPIKE	All	All	EPS	√	√	√	√		
HONDA	All	2005-2007	STEP-WGN	All	All	PGM FI	√	√	√	√		
HONDA	All	2005-2007	STEP-WGN	All	All	AT	√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	ABS TCS VSA	√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	SRS	√	√	√	√		
HONDA	All	2005-2007	STEP-WGN	All	All	EPS	√	√	√	√		
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Gauges)	√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Lighting)	√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Door Locks)	√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Keyless)	√	√	√	√	√	

HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2005-2007	STEP-WGN	All	All	BODY(Power Sliding Door)		√	√	√	√	√	
HONDA	All	2003-2004	STEP-WGN	All	All	PGM FI		√	√	√	√		
HONDA	All	2003-2004	STEP-WGN	All	All	AT		√	√	√	√	√	
HONDA	All	2003-2004	STEP-WGN	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2003-2004	STEP-WGN	All	All	SRS		√	√	√	√		
HONDA	All	2003-2004	STEP-WGN	All	All	EPS		√	√	√	√		
HONDA	All	2000-2002	STEP-WGN	All	All	PGM FI		√	√	√	√		
HONDA	All	2000-2002	STEP-WGN	All	All	AT		√	√	√	√	√	
HONDA	All	2000-2002	STEP-WGN	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2000-2002	STEP-WGN	All	All	SRS		√	√	√	√		
HONDA	All	2006-2009	STREAM	All	All	PGM FI		√	√	√	√		TP sensor reset
HONDA	All	2006-2009	STREAM	All	All	AT		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	SRS		√	√	√	√		
HONDA	All	2006-2009	STREAM	All	All	EPS		√	√	√	√		
HONDA	All	2006-2009	STREAM	All	All	BODY(Gauges)		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	BODY(Lighting)		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	BODY(Door Locks)		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	BODY(Keyless)		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	BODY(Power Windows)		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	BODY(Wiper)		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	BODY(Security)		√	√	√	√	√	
HONDA	All	2006-2009	STREAM	All	All	BODY(HVAC/Climate control)		√	√	√	√	√	
HONDA	All	2000-2006	STREAM	All	All	PGM FI		√	√	√	√		
HONDA	All	2000-2006	STREAM	All	All	AT		√	√	√	√	√	

HONDA	All	2000-2006	STREAM	All	All	ABS TCS VSA		√	√	√	√	√	
HONDA	All	2000-2006	STREAM	All	All	SRS		√	√	√	√		
HONDA	All	2000-2004	VAMOS	All	All	PGM FI		√	√	√	√		
HONDA	All	2000-2004	VAMOS	All	All	ABS TCS VSA		√	√	√	√		
HONDA	All	2000-2004	VAMOS	All	All	SRS		√	√	√	√		
HONDA	All	2000-2004	VAMOS	All	All	EPS		√	√	√	√		

OBID2 - Shop. ept