

How to read this list:	
Mark	Description
√	Function is supported.
*	Function is added or developed newly

V30/PC-MAX Function List									
Automaker:			Isuzu						
Software Version:			V2.2						
Automa ker	Year	Model	ECU Type	System	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-TC Bosch	Powertrain	√	√	√	√	√
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JA1-TC Bosch	Powertrain	√	√	√		
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	2.XL L4 HV240	Powertrain	√	√	√	√	√
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	2.5L 4JK1-TC	Powertrain	√	√	√		
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.0L 4JJ1-TC	Powertrain	√	√	√		
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.5L V6 6VE1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AT JR405E	Powertrain	√	√	√	√	√
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AW30-40LE	Powertrain	√	√	√		
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Chassis	ABS	√	√	√		
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Immobiliser	√	√	√		
ISUZU	(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Airbag	√	√	√	√	√
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine	√				
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	4HV1(CNG)	Engine	√	√	√	√	√
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	4HK1-TC (C/Rail)	Engine	√	√	√		
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	4HL1-TC (C/Rail)	Engine	√	√	√		
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	4HL1-NA (C/Rail)	Engine	√	√	√		
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	MIMAMORI	Engine	√	√	√		
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	Hybrid System	Engine	√	√	√		
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	Transmission	Smoother-E	√	√	√		
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	Transmission	Smoother / Smo	√	√	√		
ISUZU	(6) 2006	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR	√	√	√		
ISUZU	(6) 2006	(Off-Road) Industrial Engine	4JJ1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(6) 2006	(Off-Road) Industrial Engine	4HK1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(6) 2006	(Off-Road) Industrial Engine	6HK1-TC (C/Rail_TIER3)	Engine	√	√	√		

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

ISUZU	(6) 2006	(Off-Road) Industrial Engine	6UZ1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(6) 2006	(Off-Road) Industrial Engine	6WG1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-TC Bosch	Powertrain	√	√	√	√	√
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JA1-TC Bosch	Powertrain	√	√	√		
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	2.XL L4 HV240	Powertrain	√	√	√	√	√
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	2.5L 4JK1-TC	Powertrain	√	√	√		
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.0L 4JJ1-TC	Powertrain	√	√	√		
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.5L V6 6VE1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AT JR405E	Powertrain	√	√	√	√	√
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AW30-40LE	Powertrain	√	√	√		
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Chassis	ABS	√	√	√		
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Immobiliser	√	√	√		
ISUZU	(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Airbag	√	√	√	√	√
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4JG2	Engine		√	√	√	√
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4HG1(LPG)	Engine	√	√	√	√	√
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4JG2(LPG)	Engine	√	√	√	√	√
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4HV1(CNG)	Engine	√	√	√	√	√
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4HK1-TC (C/Rail)	Engine	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4HL1-TC (C/Rail)	Engine	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	4HL1-NA (C/Rail)	Engine	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	MIMAMORI	Engine	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	Hybrid System	Engine	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	Transmission	Smoother-E	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	Transmission	Smoother / Smo	√	√	√		
ISUZU	(5) 2005	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR	√	√	√		
ISUZU	(5) 2005	(Off-Road) Industrial Engine	4JJ1-TC (C/Rail_TIER3)	Engine	√				
ISUZU	(5) 2005	(Off-Road) Industrial Engine	4HK1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(5) 2005	(Off-Road) Industrial Engine	6HK1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(5) 2005	(Off-Road) Industrial Engine	6UZ1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(5) 2005	(Off-Road) Industrial Engine	6WG1-TC (C/Rail_TIER3)	Engine	√	√	√		
ISUZU	(4) 2004	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(4) 2004	(UE) Rodeo/Amigo, Wizard/MU	3.5L V6 6VE1 Hitachi	Powertrain	√	√	√		
ISUZU	(4) 2004	(UE) Rodeo/Amigo, Wizard/MU	Chassis	TPMS (Tire Pres	√	√	√	√	√
ISUZU	(4) 2004	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS	√	√	√	√	
ISUZU	(4) 2004	(UE) Rodeo/Amigo, Wizard/MU	Body	Immobiliser	√	√	√		
ISUZU	(4) 2004	(UP) Axiom	3.5L V6 6VE1 Hitachi	Powertrain	√	√	√		
ISUZU	(4) 2004	(UP) Axiom	Chassis	ABS	√	√	√	√	
ISUZU	(4) 2004	(UP) Axiom	Body	Immobiliser	√	√	√		

ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-TC Bosch	Powertrain	√	√	√	√	√
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-T Denso	Powertrain	√	√	√		
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JA1-TC Bosch	Powertrain	√	√	√		
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	2.XL L4 HV240	Powertrain	√	√	√	√	√
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.5L V6 6VE1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AT JR405E	Powertrain	√	√	√	√	√
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AW30-40LE	Powertrain	√	√	√		
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Chassis	ABS	√	√	√		
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Immobiliser	√	√	√		
ISUZU	(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Airbag	√	√	√	√	√
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine	√	√	√		
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	4JG2	Engine		√	√	√	√
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	4HF1(CNG)	Engine	√	√	√	√	√
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	4HG1(LPG)	Engine	√	√	√	√	√
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	4JG2(LPG)	Engine	√	√	√	√	√
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	4HL1-TC (C/Rail)	Engine	√	√	√		
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	4HL1-NA (C/Rail)	Engine	√	√	√		
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	MIMAMORI	Engine	√	√	√		
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	Hybrid System	Engine	√	√	√		
ISUZU	(4) 2004	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR	√	√	√		
ISUZU	(3) 2003	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(3) 2003	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain	√	√	√		
ISUZU	(3) 2003	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(3) 2003	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain	√	√	√		
ISUZU	(3) 2003	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser	√	√	√		
ISUZU	(3) 2003	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser (DD)	√	√	√		
ISUZU	(3) 2003	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	√	√	√	√	√
ISUZU	(3) 2003	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(3) 2003	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(3) 2003	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain	√	√	√		
ISUZU	(3) 2003	(UE) Rodeo/Amigo, Wizard/MU	Body	Immobiliser	√	√	√		
ISUZU	(3) 2003	(UP) Axiom	3.5L V6 6VE1	Powertrain	√	√	√		
ISUZU	(3) 2003	(UP) Axiom	4L30E	Powertrain	√	√	√		
ISUZU	(3) 2003	(UP) Axiom	Chassis	ABS	√	√	√	√	
ISUZU	(3) 2003	(UP) Axiom	Body	Immobiliser	√	√	√		
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-TC Bosch	Powertrain	√	√	√	√	√
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-T Denso	Powertrain	√	√	√		
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JA1-TC Bosch	Powertrain	√				
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	2.XL L4 SOHC	Powertrain	√	√	√	√	√

ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.5L V6 6VE1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AT JR405E	Powertrain	√	√	√	√	√
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AW30-40LE	Powertrain	√	√	√		
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Chassis	ABS	√	√	√		
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Immobiliser	√	√	√		
ISUZU	(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	Body	Airbag	√	√	√	√	√
ISUZU	(3) 2003	(TBR).	2.XL L4 HV240	Powertrain	√	√	√	√	√
ISUZU	(3) 2003	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine	√	√	√		
ISUZU	(3) 2003	(N*) ELF, NPR, NQR,VFR	4HL1/4HJ1(COMMON RAIL)	Engine	√	√	√		
ISUZU	(3) 2003	(N*) ELF, NPR, NQR,VFR	4HL1/4HJ1(Vehicle Interface Module)	Engine	√	√	√		
ISUZU	(3) 2003	(N*) ELF, NPR, NQR,VFR	4JG2	Engine		√	√	√	√
ISUZU	(3) 2003	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR	√	√	√		
ISUZU	(2) 2002	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(2) 2002	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain	√	√	√		
ISUZU	(2) 2002	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(2) 2002	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain	√	√	√		
ISUZU	(2) 2002	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser	√	√	√		
ISUZU	(2) 2002	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser (DD)	√	√	√		
ISUZU	(2) 2002	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	√	√	√	√	√
ISUZU	(2) 2002	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(2) 2002	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(2) 2002	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain	√	√	√		
ISUZU	(2) 2002	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS	√	√	√	√	
ISUZU	(2) 2002	(UE) Rodeo/Amigo, Wizard/MU	Body	Immobiliser	√	√	√		
ISUZU	(2) 2002	(UP) Axiom	3.5L V6 6VE1	Powertrain	√	√	√		
ISUZU	(2) 2002	(UP) Axiom	4L30E	Powertrain	√	√	√		
ISUZU	(2) 2002	(UP) Axiom	Chassis	ABS	√	√	√	√	
ISUZU	(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	ZJH1-TC Bosch	Powertrain	√	√	√	√	√
ISUZU	(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JH1-T Denso	Powertrain	√	√	√		
ISUZU	(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	4JA1-TC Bosch	Powertrain	√				
ISUZU	(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo	AT JR405E	Powertrain	√	√	√	√	√
ISUZU	(2) 2002	TF/UC Thailand	4JH1-T Denso	Powertrain	√	√	√		
ISUZU	(2) 2002	(TBR).	2.2L L4 HV240	Powertrain	√	√	√		
ISUZU	(2) 2002	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine	√	√	√		
ISUZU	(2) 2002	(N*) ELF, NPR, NQR,VFR	4HL1/4HJ1(COMMON RAIL)	Engine	√	√	√		
ISUZU	(2) 2002	(N*) ELF, NPR, NQR,VFR	4HL1/4HJ1(Vehicle Interface Module)	Engine	√	√	√		
ISUZU	(2) 2002	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR	√	√	√		
ISUZU	(1) 2001	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain	√	√	√		

ISUZU	(1) 2001	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain	√	√	√		
ISUZU	(1) 2001	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(1) 2001	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain	√	√	√		
ISUZU	(1) 2001	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser	√	√	√		
ISUZU	(1) 2001	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser (DD)	√	√	√		
ISUZU	(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	√	√	√	√	√
ISUZU	(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain	√	√	√		
ISUZU	(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS	√	√	√	√	
ISUZU	(1) 2001	(UE) Rodeo/Amigo, Wizard/MU	Body	Immobiliser	√	√	√		
ISUZU	(1) 2001	(UG) V-Cross	3.2L V6 6VD1	Powertrain	√	√	√	√	√
ISUZU	(1) 2001	(UG) V-Cross	3.5L V6 6VE1	Powertrain	√	√	√	√	√
ISUZU	(1) 2001	(UG) V-Cross	4L30E	Powertrain	√	√	√	√	√
ISUZU	(1) 2001	(UC) Frontier, LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(1) 2001	TF/UC Thailand	4JH1-T Denso	Powertrain	√	√	√		
ISUZU	(1) 2001	(TF) LUV	4JH1-TC Bosch	Powertrain	√	√	√	√	√
ISUZU	(1) 2001	(TF) LUV	4JA1-TC Bosch	Powertrain	√	√	√		
ISUZU	(1) 2001	(TF) LUV	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(1) 2001	(TF) LUV	Body	Immobiliser	√	√	√		
ISUZU	(1) 2001	(N*) ELF, NPR, NQR,VFR	4JH1-TC Bosch	Engine	√	√	√		
ISUZU	(1) 2001	(N*) ELF, NPR, NQR,VFR	Chassis	ABS / ASR	√	√	√		
ISUZU	(Y) 2000	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(Y) 2000	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain	√	√	√		
ISUZU	(Y) 2000	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(Y) 2000	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain	√	√	√		
ISUZU	(Y) 2000	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser	√	√	√		
ISUZU	(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	√	√	√	√	√
ISUZU	(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	√	√	√		
ISUZU	(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain	√	√	√		
ISUZU	(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS	√	√	√	√	
ISUZU	(Y) 2000	(UG) V-Cross	3.2L V6 6VD1	Powertrain	√	√	√	√	√
ISUZU	(Y) 2000	(UG) V-Cross	3.5L V6 6VE1	Powertrain	√	√	√	√	√
ISUZU	(Y) 2000	(UG) V-Cross	4L30E	Powertrain	√	√	√	√	√
ISUZU	(Y) 2000	(UC) Frontier, LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(Y) 2000	(UC) Frontier, LAO-Rodeo	Body	Immobiliser	√	√	√		
ISUZU	(Y) 2000	(TF) LUV	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain	√	√	√	√	√

ISUZU	(X) 1999	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(X) 1999	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser	√	√	√		
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS	√	√	√	√	
ISUZU	(X) 1999	(UG) V-Cross	3.2L V6 6VD1	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UG) V-Cross	3.5L V6 6VE1	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UG) V-Cross	4L30E	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(UC) Frontier, LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(X) 1999	(TF) LUV	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser	√	√	√		
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	√	√	√		
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS	√	√	√	√	
ISUZU	(W) 1998	(UC) Frontier, LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(TF) LUV	3.2L V6 6VD1 Hitachi	Powertrain	√	√	√	√	√
ISUZU	(W) 1998	(TF) LUV	2.2L L4 SOHC	Powertrain	*	*	*	*	*